

---

## *Table of Contents*

---

<b>Introduction .....</b>	<b>1-1</b>
Key Features and Benefits of the EIDEPRO .....	1-1
<b>Getting Started .....</b>	<b>2-1</b>
Unpacking your EIDEPRO .....	2-1
EIDEPRO Board Layout .....	2-2
Configuring your EIDEPRO Jumpers Settings .....	2-3
Quick Installation Guide .....	2-4
<b>Configuration and Installation .....</b>	<b>3-1</b>
Overview of EIDEPRO Installation Steps .....	3-1
Check your EIDEPRO Factory Default Jumper Settings .....	3-1
Configure your EIDEPRO Jumper Settings .....	3-3
Install the EIDEPRO Into Your System .....	3-8
Configure Your Mainboard BIOS Setup .....	3-12
<b>DOS Windows 3.1x/Windows95 Operating Systems .....</b>	<b>4-1</b>
Working with Existing OS Installations .....	4-1
Installing DOS .....	4-1
Installing Microsoft Windows 3.1x or Windows95 .....	4-1
The EIDEPRO Windows 3.1x Driver Setup Utility .....	4-2
Manually installing Windows 3.1x Drivers .....	4-3
<b>Other Operating Systems .....</b>	<b>5-1</b>
IBM OS/2 2.x and OS/2 3.0 Warp .....	5-1
Microsoft Windows NT 3.1, 3.5x .....	5-1
NetWare 3.xx & 4.x .....	5-1
UNIX / LINUX .....	5-1
<b>In Case of Trouble .....</b>	<b>6-1</b>
Problems accessing previously formatted drives .....	6-1
Eliminate Master/Slave combination problems .....	6-2
Disable Onboard IDE controllers .....	6-2
IBM PS/1 and ValuePoint .....	6-2
Ontrack Disk Manager and other drive translation software .....	6-3
Partitioning and Formatting IDE drive(s) .....	6-4
ATAPI IDE CD-ROM Installation .....	6-5

---

## *Table of Contents*

---

Coexist with and boot to a SCSI adapter .....	6-5
Boot to SCSI .....	6-5
Boot to IDE .....	6-5
QEMM Int76 ROM handler error .....	6-5
Windows for Workgroups 3.11 32-bit File Access .....	6-6

### **APPENDIX**

Contacting Technical Support .....	A-1
Warranty Information .....	B-1
Limited Warranty .....	B-1
Disclaimer of Other Warranties .....	B-1
Returning a Product for Repair .....	C-1
Your Responsibilities .....	C-2