





Wire KBC socket pin 39 to Pin 27
Wire KBC or KBC socket pin 36 to IRQ12 on motherboard's ISA slot
Cut pins 23, 24, 27 & 28 such that they do not make contact with the motherboard's DIP-40 Socket. Put electrical tape over these cut pin ends.

Bend out pins 38 & 39 so that these pins do not go into the socket. You will need to solder wires to these pins.