

SCSI ID ADDRESS	ID2	ID1	ID0
0	ON	ON	ON
1	ON	ON	OFF
2	ON	OFF	ON
3	ON	OFF	OFF
4	OFF	ON	ON
5	OFF	ON	OFF
6	OFF	OFF	ON
7	OFF	OFF	OFF

(Table 10-3) SCSI ID setting

(2)SCSI parity strap

"PAR" on the PCBA is the parity strap. When "PAR" is ON, the FC-1 performs parity checking (odd number) of input: data (-DB0 ~ -DB7, -DBP). Parity checking does not take place when "PAR" is OFF.

It is factory-set to "ON".