
Federal Communications Commission Statement

This device complies with FCC Rules Part 155. Operation is subject to the following two conditions:

- ♦ This device may not cause harmful interference
- ♦ This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy. If this equipment is not installed and used in accordance with the manufacturer's instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ♦ Reorient or relocate the receiving antenna.
- ♦ Increase the separation between the equipment and receiver.
- ♦ Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- ♦ Consult the dealer or an experienced radio/TV technician for help.

The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for audio noise emissions from digital apparatuses set out in the Radio Interference Regulations of the Canadian Department of Communications.

Manufacturer's Disclaimer Statement

The information in this document is subject to change without notice and does not represent a commitment on the part of the vendor. No warranty or representation, either expressed or implied, is made with respect to the quality, accuracy or fitness for any particular purpose of this document. The manufacturer reserves the right to make changes to the content of this document and/or the products associated with it at any time without obligation to notify any person or organization of such changes. In no event will the manufacturer be liable for direct, indirect, special, incidental or consequential damages arising out of the use or inability to use this product or documentation, even if advised of the possibility of such damages. This document contains materials protected by copyright. All rights are reserved. No part of this manual may be reproduced or transmitted in any form, by any means or for any purpose without expressed written consent of its authors. Product names appearing in this document are mentioned for identification purposes only. All trademarks, product names or brand names appearing in this document are registered property of their respective owners.

Printed in Taiwan



Table of Contents

Chapter 1 Introduction	1
1-1 Product Specifications	1
1-2 Package Contents	4
1-3 Mainboard Layout	5
1-4 Connector and Jumper Reference Chart	5
Chapter 2 Hardware Setup	7
2-1 Introduction to Jumpers	7
2-2 Installing an S.E.C. Processor in Slot 1	8
2-3 Setting Your CPU's Parameters(SeePU Technology)	9
2-4 Connector and Jumper Settings	11
2-5 Main Memory Configuration	18
Chapter 3 Award BIOS Setup Program	21
3-1 Standard CMOS Setup	22
3-2 BIOS Features Setup	25
3-3 SeePU & Chipset Setup	28
3-4 Power Management Setup	31
3-5 PnP/PCI Configuration	36
3-6 Load Setup Defaults	38
3-7 Integrated Peripherals	39
3-8 Supervisor Password & User Password Setting	41
3-9 IDE HDD Auto Detection	43
3-10 Save and Exit Setup	43
3-11 Exit Without Saving	43
Chapter 4 Brief Software Driver Guide	45
- Bus Master/PIO IDE Driver Installation	
- USB Driver Installation	
- Removing the Exclamation and/or Question Marks From the Windows 95 Device Manager Menu	
- Updating Your System BIOS	
- Installing and Using a Desktop Management Interface (DMI) Utility	
Feature Explanations	
SeePU Technology	9
Software Power-off Control	11
Power-On By Modem	11/34

Over-ride Power Button	12
Blinking LED in Suspend Mode	12
Wake Up On LAN	14/34
Creative's SB-LINK Sound	15
Power-On by Keyboard	15/40
Poly-fuse Over Current Protection	16
Chassis Intrusion Monitoring	16
Power Failure Recovery	16/29
ECC DRAM Capability	19
Flash BIOS Protection	30
Power-On by Alarm	34

Appendices

Appendix I On Board I/O Addresses & IRQ Maps	47
Appendix II Quick Connector and Jumper Reference.....	49
Appendix III FAN-II <i>SMART</i> Technology Upgrade Kit	51
Reader's Feedback	53



Memo